

Also available in the Optimum Time Range:

**Ultimate Event Watch**

**Ultimate Sailing Watch**

**Ultimate 3 Day Event Watch**

**Ultimate Endurance Watch**

**Ultimate Rugby Timer**

**Ultimate Hockey Timer**

**OPTIMUM TIME**

P.O. BOX 39  
Market Deeping  
Peterborough  
PE6 8XQ  
England

Tel +44 (0) 1733 333324

Fax +44 (0) 1733 333700



Optimum Time

**Ultimate Football / Hockey / Rugby Watches**

Instructions

## THE ULTIMATE FOOTBALL / HOCKEY / RUGBY WATCHES

"THE ULTIMATE FOOTBALL / HOCKEY / RUGBY WATCHES" ARE WATER RESISTANT WATCHES WHICH FEATURE TIME OF DAY, A COUNTUP (FROM ZERO) TIMER, AND A PROGRAMMED COUNTDOWN TIMER WITH ALARM.

ONCE THE TIMER IS RUNNING, ONLY THE START/STOP BUTTON AND THE MODE BUTTON HAVE ANY FUNCTION.

AT ANY TIME A BUTTON IS PRESSED THAT IS GOING TO HAVE ANY FUNCTION THE ALARM SOUNDS A SINGLE BEEP.

①



②

## OPERATING INSTRUCTIONS

### TO SET THE TIME

1. Put the watch into time mode by pressing the "**MODE**" button. (The time mode can be recognised by the flashing colon between the hours and minutes digits and also by either "**AM**" or "**PM**" being visible at the top of the display.
2. Press the "**CLEAR**" button and hold it down for approximately 2 seconds until the display begins to flash.
3. Press the "**NORMAL TIME**" button (marked "**NORMAL TIME**") until the correct hour is shown.

- Notes**
- a) Each time you press the button the time will advance 1 hour.
  - b) Keeping the button pressed in for a couple of seconds will start fast scrolling through the hours.
  - c) The time is a 12 hour mode with AM/PM indicator.

4. Once the correct hour is set, press the "**EXTRA TIME**" button (marked "**EXTRA TIME**"). This will alter the minutes in the same way as the hours were set.
5. Once the correct hours and minutes are set, press the "**CLEAR**" button one more time and the time is set and running. The display will also stop flashing.

### TO LEAVE THE TIME FUNCTION

1. Press the "**MODE**" button. This will change the unit from time to timer mode.
2. Pressing the "**MODE**" button again will revert to the time.
3. It is possible to change from time to timer or timer to time regardless of whether the timer is running or not.
4. Once in the timer mode there are 2 options: COUNTUP OR COUNTDOWN.

③

## COUNTUP OPTION

1. Once in the time mode press the "**CLEAR**" button. This will only function if the timer is not running. (If the timer is running press the "**STOP**" button first and then press the "**CLEAR**" button). This display will now show 0.00.
2. Press the "**START**" button and the timer will countup from zero in minutes and seconds up to a maximum of 59 mins 59 secs. The display will also show the word "**COUNTUP**".
3. During countup the timer can be stopped and restarted as many times as required.

## PROGRAMMED COUNTDOWN MODE

1. To utilise the programmed countdown option first leave the clock mode by pressing the "**MODE**" button.
2. If the timer is running press the "**STOP**" button.
3. Press the "**CLEAR**" button. (The display will now show 0.00)
4. Press the "**NORMAL TIME**" button (marked "**NORMAL TIME**") once. The display will now show 45:00, 35:00 or 40:00 for Football, Hockey and Rugby timer respectively. I.E. the timer is programmed for a 45, 35, or 40 minute period.
5. Press the "**START**" button and the timer will countdown in minutes and seconds towards zero. The display will also show the word "**COUNTDOWN**".
6. During countdown the timer can be stopped and restarted as many times as required.
7. When the timer has counted down to 3 seconds before 0.00 an alarm sounds. This sounds one short "**pip**" for each of the 3 seconds plus 4 short "**pips**" exactly at zero, and for the following four seconds. Upon reaching zero the timer will begin to countup again. The display will also change to show the word "**COUNTUP**". This will countup to a maximum of 59 mins 59 seconds. This will display the amount of stoppage time elapsed.

④

8. If extra time is to be played or a game with shorter halves, then the "EXTRA TIME" button (marked "EXTRA TIME") can be used to get multiples of one minutes. Once the timer reaches zero the alarm will once again sound.

### LOW BATTERY INDICATOR

The watch is equipped with a low battery indicator located in the top right hand side of the display. When the indicator is on, it is time to change the battery.



### TO CHANGE THE BATTERY

1. Using a cross-point screwdriver carefully remove all 4 screws from the watch and remove the case back from the case front to reveal the battery.
2. Remove the old battery and replace it with a new one making sure the +ve contact faces upwards. (Avoid holding the battery so that your fingers touch both the +ve & -ve contacts at the same time).
3. The battery type is a CR2032 3.0V lithium battery.
4. Replace the case back making sure that the battery is correctly fitted, that the rubber seal around the case back is seated properly, and that the case back fits without interference.
5. Replace the 4 screws taking care not to overtighten them to the point of stripping the thread.

⑤

### TO SEE THE DISPLAY IN THE DARK

Press the "☀️" button at any time to light up the LCD display. The EL will go out automatically approximately 3 seconds later. If you require longer illumination than 3 seconds keep pressing the button.

### NOTES

1. Under extreme conditions LCD watches can be affected by heat & sunlight. Your Optimum Time watch has a high temperature display for this reason.

When affected an LCD display turns black. When allowed to cool down it will return to normal. You should not experience this with an Optimum Time product but please avoid leaving the watch in a hot and bright environment such as on a car dashboard.

2. Electronic watches can suffer from static electricity. This may result in a watch locking up so that nothing functions. Optimum Time watches have static protection, but the level of static varies from person to person. If your watch locks up, it can be corrected by pressing all of the buttons at once, holding them down a few seconds. Unfortunately the time will need resetting after this is done.

⑥