



Optimumtime

**Ultimate Football Timer**


Instructions

## **THE ULTIMATE FOOTBALL TIMER**

**“THE ULTIMATE FOOTBALL TIMER” IS A WATERPROOF TIMER WITH JUMBO DISPLAY, AND FEATURES A CLOCK, A COUNTUP (FROM ZERO) TIMER WITH ALARM, AND A PROGRAMMED COUNTDOWN TIMER WITH ALARM.**

**THE BUTTONS HAVE A POSITIVE CLICK-TYPE OPERATION AND ARE ALSO ON THE TOP PANEL TO PREVENT ACCIDENTAL KNOCKING. ONCE THE TIMER IS RUNNING ONLY THE START/STOP BUTTON AND THE MODE BUTTON HAVE ANY FUNCTION.**

**AT ANY TIME A BUTTON IS PRESSED THAT IS GOING TO HAVE ANY FUNCTION THE ALARM SOUNDS A SINGLE BEEP.**



## OPERATING INSTRUCTIONS

### TO SET THE TIME

1. Put the timer into clock mode by pressing the "MODE" button. (The clock mode can be recognised by the flashing colon between the hours and minutes digits and also by either "AM" or "PM" being visible at the top of the display.)
2. Press the "CLEAR" button and hold it down for approximately 2 seconds until the display begins to flash.
3. Press the "NORMAL TIME" Button (marked "NORMAL TIME") until the correct hour is shown.

- Notes**
- a) Each time you press the button the clock will advance 1 hour.
  - b) Keeping the button pressed in for a couple of seconds will start fast scrolling through the hours.
  - c) The clock is a 12 hour clock with AM/PM indicator.

4. Once the correct hours is set, press the "EXTRA TIME" button (marked "EXTRA TIME"). This will alter the minutes in the same way as the hours were set.
5. Once the correct hours and minutes are set, press the "CLEAR" button one more time and the clock is set and running. The display will also stop flashing.

### TO LEAVE THE CLOCK FUNCTION

1. Press the "MODE" button. This will change the unit from clock to timer mode.
2. Pressing the "MODE" button again will revert to the clock.
3. It is possible to change from clock to timer or timer to clock regardless of whether the timer

is running or not.

4. Once in the timer mode there are 2 options : COUNTUP OR COUNTDOWN.

### COUNTUP OPTION

1. Once in the timer mode press the "CLEAR" button. This will only function if the timer is not running. (If the timer is running press the "STOP" button first and then press the "CLEAR" button). This display will now show 0.00.
2. Press the "START" button and the timer will countup from zero in minutes and seconds up to a maximum of 59 mins 59 secs. The display will also show the word "COUNTUP".
3. During countup the timer can be stopped and restarted as many times as required.

### PROGRAMMED COUNTDOWN MODE

1. To utilise the programmed countdown option first leave the clock mode by pressing the "MODE" button.
2. If the timer is running press the "STOP" button.
3. Press the "CLEAR" button. (The display will now show 0.00).
4. Press the "NORMAL TIME" button (marked "NORMAL TIME") once. The display will now show 35.00. I.E. the timer is pre-programmed for a 35 minute period.
5. Press the "START" button and the timer will countdown in minutes and seconds towards zero. The display will also show the word "COUNTDOWN".
6. During countdown the timer can be stopped and restarted as many times as required.

4

7. When the timer has counted down to 3 seconds before 0.00 an alarm sounds. This sounds one short "pip" for each of the 3 seconds plus 4 short "pips" exactly at zero, and for the following four seconds. Upon reaching zero the timer will begin to countup again. The display will also change to show the word "COUNTUP". This will countup to a maximum of 59 mins 59 seconds. This will display the amount of stoppage time elapsed.
8. If extra time is to be played or a game with shorter halves, then the "EXTRA TIME" button (marked "EXTRA TIME") can be used to get multiples of one minutes. Once the timer reaches zero the alarm will once again sound.


### USEFUL HINTS

1. The watch can be worn just like any normal watch on the wrist. However if the display is not convenient to look at, then the whole timer case can be turned inside the outer clip to get a better viewing angle.

5

### LOW BATTERY INDICATOR


The timer is equipped with a low battery indicator located in the top left hand side of the display. When the indicator is on, it is time to change the battery.



### TO CHANGE THE BATTERY

1. Remove the timer from the outer clip.
2. Using a screwdriver to remove all 4 screws from the case back and remove the case back from the case front to reveal the battery.
3. Remove the old Battery and replace with a new one making sure the +ve contact faces upwards (Avoid holding the battery so that your fingers touch both the +ve & -ve contacts at the same time)


4. Replace the case back making sure that the O ring seal is in the correct position.
5. Replace the four screws the four screws taking care not to overtighten them and thus strip the thread.



### ADJUSTING THE ELASTIC STRAP

There is a right way and a wrong way to adjust the elastic strap. Please take note to avoid any chance of the strap coming undone.

1. Place the watch on the wrist and pass the elastic through the clasp from the bottom to the top.
2. Pull the elastic to the required tightness and secure by pressing the clasp firmly closed.
3. Push the elastic loop over the spare length of elastic to keep the loose end tidy.



Also available in the Optimum Time Range:

**Ultimate Event Watch - The Classic**

**Ultimate Sailing Watch - The Classic**

**The Timesaver - Event Timing Equipment**

**3 Day Event Watch - The Classic & The Compact**

**Ultimate Endurance Watch - The Classic & The Compact**

**Ultimate Football Timer - The Classic & The Compact**

**Ultimate Rugby Timer - The Classic & The Compact**

**Ultimate Hockey Timer - The Classic & The Compact**

**Heart Rate Monitor's**

**Optimum Time Ltd.**

P.O. Box 39  
Market Deeping  
Peterborough  
PE6 8XQ  
England

Tel 01733 333324 Fax 01733 333700  
International Tel +44 1733 333324 Fax +44 1733 333700  
[www.optimumtime.co.uk](http://www.optimumtime.co.uk)